



SILVERTON

MARINE CORPORATION AN EMPLOYEE OWNERSHIP COMPANY

SERVICE BULLETIN

BULLETIN : 1-05

DATE: 3/14/2005

SUBJECT: 48C WASTE SYSTEM SENDER FIX

HULL #s: #031-077 (EXCULDING #059)

Situation: On 48 Convertible hulls #031 through #077 (except for hull #059) the holding tank was installed in a way that could result in overfilling of the holding tank. A reinforcement rib across the top of the tank isolates the FULL level float from the vent line. Once the tank contents reach this rib, air is trapped on the FULL float side, preventing the tank contents from activating the float and keeping the FULL level indicator light from illuminating. Meanwhile, the tank level can continue to rise on the vented side and fill the vent line with effluent without the owner being aware of the problem.

Solution: To eliminate this problem, a FULL level float retrofit kit is being supplied by Dometic.

Please see the attached Dometic Service Bulletin for further installation information and contact information



Technical Service Announcement

Dometic Corporation – Sanitation Systems
 13128 State Rt. 226, P.O. Box 38, Big Prairie, Ohio 44611 U.S.A.
 Telephone 330/496-3211 800/321-9886 Fax: 330/496-3097

Bulletin Number : 1025
Effective Date: January 2005

Holding Tanks on 48 Convertibles

Situation: On 48' Convertible hulls #031 through #077, except for hull #059, the holding tanks were installed in a way that could result in overfilling of the holding tank. A reinforcement rib across the top of the tank isolates the FULL level float from the vent line. Once the tank contents reach this rib, air is trapped on the FULL float side, preventing the tank contents from activating the float, and keeping the FULL level indicator light from illuminating. Meanwhile the tank level can continue to rise on the vented side and fill the vent line with effluent.

Solution: To eliminate this problem, a FULL level float retrofit kit is being supplied by Dometic. The retrofit installation requires cutting the wires to the existing FULL level float, installing the new float in the tank near the vent line, and attaching the existing wires to the new FULL float. Detailed instructions are included with the retrofit kit.



Among the series of three floats is the FULL level float. Be sure to cut only the wire with "FULL" label attached. If no labels are attached, the floats must be removed until the one matching the new FULL float is identified.



Existing float location on holding tank system

New FULL float location

Service Coverage:

- € Float kit available at no charge from Dometic Sanitation Systems.
- € One hour of labor will be reimbursed to install float kit.
- € Please contact Customer Service for float kit and reimbursement at 1-800-321-9886, Mon-Fri 8-5 ET. Fax 330-496-3211